



**Read Before Use**

As a precaution, gloves and eye protection should be worn when handling drug substances and using test units. Do not puncture any part of unit. Do not remove probe once a capsule is broken. In the unlikely event of a spill, rinse affected area thoroughly with water. Keep out of reach of children. All results are presumptive. If necessary, further testing by a competent drug testing lab can provide additional identification.

<b>Test Preparation</b>	<b>1</b>	Remove the Smart-Tip™ probe from test unit.	<b>2</b> Sample suspected substance.	
			Powder	Tablet/Brick
		<p>Touch Smart-Tip™ probe to sample.</p>	<p>Firmly press Smart-Tip™ probe on the tablet while scrubbing in a circular motion until the tip is completely covered with substance.</p>	

<b>Test Preparation</b>	<b>3</b>	Lock Smart-Tip™ probe into test unit. Press firmly.	<b>STOP</b> <b>Do not continue unless probe is locked below the Flex Pins and cannot be removed from the test unit.</b>	<b>Identification</b>	<b>4</b>	With <b>thumb and forefinger</b> , squeeze chamber 1 until capsule breaks.	<b>5</b>	Gently shake test unit for 2-3 seconds.
	<p>Flex Pins</p>							

<b>Results</b>		The appearance of a purple color indicates the presence of an opiate such as <b>Heroin, Morphine or Codeine</b> .
		If no purple color develops, an opiate, such as Heroin, Morphine or Codeine, is <b>not</b> present.
		<b>Proceed to Dilution (steps 6-9), regardless of whether or not a color appeared.</b>

<b>Dilution</b>	<b>6</b>	With <b>thumb and forefinger</b> , squeeze chamber 2 until capsule breaks.	<b>7</b>	Gently shake test unit for 2-3 seconds.
			<p style="color: red;">Wait 5 minutes. The test window will warm up. This is normal.</p>	

<b>Dilution</b>	<b>8</b>	With <b>thumb and forefinger</b> , squeeze chamber 3 until capsule breaks.	<b>9</b>	Gently shake test unit for 2-3 seconds.
			<p>The test window will warm up. This is normal.</p>	



**Disposal**

After Dilution, the test kit is safe to dispose of in the trash.