



TESTING KITS FOR DRUGS

# Procedure Card for IDT6000

## LSD IDENTIFICATION

### Substance Test



**Read Before Use**

As a precaution, gloves and eye protection should be worn when handling drug substances and using test units. Do not puncture any part of unit. Do not remove probe once a capsule is broken. In the unlikely event of a spill, rinse affected area thoroughly with water. Keep out of reach of children. All results are presumptive. If necessary, further testing by a competent drug testing lab can provide additional identification.

<b>Test Preparation</b>	<b>1</b>	Remove the Smart-Tip™ probe from test unit.	<b>2</b> Sample suspected substance.	
			<b>Blotter (Stamp)</b>	<b>Tablet</b>
			Roll and insert it into the hole. 	Firmly press Smart-Tip™ probe on the tablet while scrubbing in a circular motion until the tip is completely covered with substance. 

<b>Test Preparation</b>	<b>3</b>	Lock Smart-Tip™ probe into test unit. Press firmly.	<b>STOP</b> <b>Do not continue unless probe is locked below the Flex Pins and cannot be removed from the test unit.</b>	<b>Identification</b>	<b>4</b>	With <b>thumb and forefinger</b> , squeeze chamber 1 until capsule breaks.	<b>5</b>	Gently shake test unit for 20 seconds.

<b>Identification</b>	<b>6</b>	With <b>thumb and forefinger</b> , squeeze chamber 2 until capsule breaks.	<b>7</b>	Gently shake test unit for 2-3 seconds.

**Results**



The appearance of a purple-violet color indicates the presence of **LSD** (lysergic acid diethylamide) or **DMT** (dimethyltryptamine).



If no violet-purple color develops, LSD and DMT are not present.



**Disposal**

The test kit is safe to dispose of in the trash.

01-19



**Manufactured by IDenta Ltd**

www.identa-corp.com

Patented Technology

Made in Israel